


Operating Instructions 2 Lever Synchro Mechanism

Back Height

Lift slowly to raise back, locks with each click. When at the top, back falls back to lowest position in order to repeat cycle.



Optional seat slide

Lift lever to operate slide when fitted

Seat Height

Twist lever upwards to operate gas height adjustment.



Back/Seat Tilt.

Twist lever up & lean back to enter free floating synchronized seat/back rake mode. To lock when in desired position, twist lever down.

Tilt Tension

Counterbalances body weight when in free float. Turn clockwise to increase force.